GlobalStar



LUSID TECHNOLOGIES

L2.1.K2 High Gloss Low VOC Alkyd

US/10132016L2.1.K2

Technical Data Sheet

Description

High Gloss Low VOC Alkyd Topcoat, L2.1.K2 is compliant in all restricted VOC areas.

Suggested Uses

As a high gloss topcoat over the following primers. P9.3.K1 2K Epoxy Primer. Over primed steel substrate where:

- Outstanding gloss and corrosion resistance is required.
- Outstanding flexibility is needed.

Excellent performance when applied with airless, air-assist airless pressure pot, cup gun or brush or rolled.

Components

L2.1.K2 Base GSOR-F, GSOR-M, GSOR-S Fast, Medium, Slow, AV.002 Hardener (optional)

Fast, Medium, Slow, Zero VOC Reducers Hardener (optional)

Field Applications

- Coachwork or bus frames, undercarriage and bumpers.
- Work trucks, panel trucks trailers.
- truck and trailer frames.
- wood

Mixing Ratio

Mix:

Mix eight (8) parts Base Color to one (1) part AV.002 Hardener (optional). May be reduced 15%-25% with appropriate Reducer above.

Application

Apply:

Two medium wet coats, allow 25-35 minutes flash between coats.

GlobalStar Industrial

Division of Lusid Technologies, Inc. | Salt Lake City, UT | Phone 877-973-7600 | Fax 801-966-6876

GlobalStar

L2.1.K2 IN High Gloss Low VOC Alkyd



US/10132016L2.1.K2

Or Apply one medium light coat followed by a medium cross coat.

Spray Gun:

HVLP Gravity Feed – 1.4 - 1.6mm tip and needlePressure Pot HVLP – 1.0 - 1.1mm tip and needleAir Assist Airless-1.0 - 1.1mm tip and needleConventional-1.4 - 1.7mm tip and needleAirless-310 - 610 - 312 - 612 nozzle50-75 microns – (2.0 - 3.0 mils.)

60 minutes @ 20° C (68° F)

45 minutes @ 60° C (140° F)

Maximum resistance after 7 days

4-8 hours @ 20° C (68° F) 24-48 hours @ 20° C (68° F)

Film Build: Dry Times

Dust Free: Dry to Touch Total Hardness Force Dry Chemical Resistance

Surface Preparation

Ferrous metals: Best Case

Second Best Case

Third Best Case

Aluminum:

SA2 sandblast Blow all dust and contaminates off and apply suitable Globalstar primer within 12 hours followed by topcoat as directed.

Hot Phosphate wash system, blow dry and apply suitable Globalstar primer within 8 hours, followed by topcoat as directed.

Careful mechanical abrasion. Clean all dust, oil residue, finger prints and contaminates before and after mechanical abrasion with a clean drying wax and grease removal solvent, making sure all residue is removed. Apply suitable Globalstar primer followed by topcoat as directed.

Clean surface with clean drying wax and grease remover. Apply Globalstar Epoxy Primer followed by topcoat as directed.

Galvanized Steel:

Clean all dust, oil residue, and contaminates from surface using a

GlobalStar Industrial

Division of Lusid Technologies, Inc. | Salt Lake City, UT | Phone 877-973-7600 | Fax 801-966-6876



GlobalStar Industrial

Division of Lusid Technologies, Inc. | Salt Lake City, UT | Phone 877-973-7600 | Fax 801-966-6876